

MECER

| BATTERY | QTY | L | Н | D |
|----------------|-----|------|-----|-----|
| 100 A/H | 2 | 455 | 310 | 424 |
| 100 A/H | 4 | 805 | 310 | 424 |
| 200 A/H | 2 | 650 | 340 | 607 |
| 200 A/H | 4 | 1207 | 340 | 607 |


BATTERY PACK UNITS

STURDY KNOCK DOWN ASSY

STACKING UP TO 4 UNITS


| | L | |
|--------------|-----|----|
| (° O O | top | 00 |


CORROSION
RESISTANT ZINC
COATED STEEL




ADJUSTABLE LEVELLING FEET

ASSEMBLY
FASTENERS
&
INSTRUCTIONS
INCLUDED












BATTERY PACK UNITS



Assembly instructions

- 1: Lay Base on flat surface
- 2: Align sides on base & screw into place (4 s/tapping screws provided)
- 3: Slide rear panel into place
- 4: Place top on & use supplied 4 s/tapping screw to fasten
- 5: Insert front panel until catches click into place

Package contents

Base x 1
Rear panel x 1
Top plate x1
Sides x 2
Front panel x 1
Self tapping screws x 8
Adjustable feet x 4
+ 4 x lock nuts

